



TimerGate

Quick Start Guide

Document: TM- 1316

THETAmetrix Ltd
12 Somerset House
Hussar Court
Waterlooville
Hampshire
PO7 7SG, U.K.

Support email:
sales@THETAmetrix.co.uk

Documentation and software downloads:
<http://www.THETAmetrix.co.uk/site/downloads/software-and-manuals>



In the Box...

- 1x Printed Quick Start Guide (this document)
- Master Gate, with:
 - 1 x Master gate unit with tripod
 - 1 x Reflector with tripod
 - 1 x USB cable
- 1-3 Slave gates, depending on purchase option, each Slave gate has:
 - 1 x Slave gate unit with tripod
 - 1 x Reflector with tripod
 - 1 x Cable

PC Requirements

Minimum Requirements (recommended in brackets):

- Windows XP SP3 / Windows Vista SP2 / Windows 7 SP1 (Windows 7 SP1)
- 1 GHz Processor (1 GHz)
- 1 GB available system memory (1 GB)
- 16 GB hard disc space (16 GB)
- 128 MB video card (256 MB)
- USB port
- Internet connection, for initial software download only

Setup

Software

The software can be downloaded from the THETAmetrix website at:
<http://www.thetametrix.co.uk/site/clinician-products/timergate>

Download and run the software installer and follow the on screen instructions to install the TimerGate software. The software should be installed before the TimerGate is connected to the PC.

Hardware

- Plug the Master gate into the PC using the provided USB cable
- Connect a Slave gate to the Master gate using the provided 6pin-DIN cable
- Connect each additional Slave gate into the previous Slave gate using the provided cable
- Set up the reflector for each TimerGate unit so the red beam from the gate is visible on the yellow reflector pad and the beam goes steady (a flashing beam means the gate is not getting a clear return signal, a steady beam means the gate is getting a clear return signal). Each reflector should be positioned between 1m and 3m away from its gate.

WARNING! Do not look directly into the beam emitter on the TimerGate units. The LEDs used in the TimerGates are not powerful enough to cause eye injury (they are Class I LED light sources) but they can cause discomfort and/or irritation.